



Vitotherm

Instruction
manual

CO₂ set

CO₂ dosing unit &
control panel



EN (English) original instructions

Original instructions

The original manual is written in UK English. All other language versions are translations of the original manual.

Copyright

All rights reserved © 2024 Vitotherm BV.

No part of this publication may be reproduced and/or published by print, photoprint, microfilm or any other means without the written consent of Vitotherm BV.

Disclaimer of liability

The manufacturer cannot be held responsible for personal injury, damage to the CO₂ set or property damage caused by incorrect use, foreseeable misuse or failure to follow the instructions in this manual. This also applies to unauthorised modifications of the CO₂ set and the use of non-approved spare parts, tools or accessories.

The manufacturer reserves the right to modify this manual without notification beforehand.

Customer service

Our customer service department is available 24 hours a day to provide any required technical information and support.

Please have the type plate information of the CO₂ set available when you contact our customer service department (see §3.6).

+31 (0) 15 369 47 57

Warranty

The equipment supplied by Vitotherm has a one-year warranty covering materials from date of commissioning against defective parts, limited to the delivery of parts only. Warranty is only valid when the installation has been realised in accordance with our instructions and commissioning is executed by a Vitotherm engineer or by Vitotherm authorised personnel.

During the period of the warranty any failures to Vitotherm equipment will be repaired within 10-14 days. Our local service expert for future regular maintenance will be at our daily rate.

Table of Contents

1	Introduction	3	5	Commissioning	29
1.1	About this document	3	6	Operation	31
1.2	Symbols and labels	3	6.1	Control panel	31
1.3	Used terms and definitions	4	6.2	Switching the CO ₂ set on or off	31
1.4	Conformity	4	6.3	Performing a system reset	31
2	Safety	6	7	Troubleshooting	33
2.1	Introduction	6	8	Maintenance	35
2.2	Intended use	6	8.1	Pre-emptive parts replacement schedule	35
2.3	Reasonably foreseeable misuse	7	8.2	Annual Periodic Maintenance	35
2.4	Qualification of personnel	7	9	Transport and storage	39
2.5	Protective measures	8	9.1	Transport	39
2.6	Residual risks	9	9.2	Storage	39
2.7	Warning labels	10	10	Decommissioning and disposal	40
2.8	Safety precautions	10	10.1	Decommissioning	40
3	Design and function	12	10.2	Dismantling the CO ₂ dosing unit	40
3.1	System overview	12	10.3	Disposal	41
3.2	CO ₂ dosing unit	13	Appendices		42
3.3	Control panel	14	A	CO ₂ dosing unit orientations	42
3.4	Frequency drive	15	B	Technical data	43
3.5	Optional components	16	C	Declaration of conformity	44
3.6	Type plate	17			
3.7	Technical data	18			
3.8	Configurations	18			
4	Installation	19			
4.1	Checking the delivery	19			
4.2	Preparing the scaffold	19			
4.3	Mounting the CO ₂ dosing unit	20			
4.4	Connecting the CO ₂ dosing unit	22			
4.5	Electrical connections	27			


Vitotherm

Vitotherm
**Firing technology
becomes standard**

1 Introduction

1.1 About this document

This manual contains instructions and safety information for operation, installation, commissioning and maintenance of the Vitotherm CO₂ set.

This manual is intended for:

- the owner of the CO₂ set;
- the worker that operates the CO₂ set;
- the qualified technician that performs the installation of the CO₂ set;
- the engineer that is authorized by Vitotherm to perform (re)commissioning, adjustments, troubleshooting, maintenance and repairs of the CO₂ set.

1.2 Symbols and labels

1.2.1 Safety warnings

This manual contains safety warnings that may result in injury when ignored. Each safety warning is indicated with a signal word. The signal word corresponds with the level of risk of the described hazardous situation:

Signal word	Level of risk	If not avoided
⚠ DANGER!	High	Will result in death or serious injury
⚠ WARNING!	Medium	Could result in death or serious injury
⚠ CAUTION!	Low	Could result in moderate or minor injury

Safety warnings given at the start of a section apply to the entire section.

Format example of a safety warning:

⚠ WARNING!	Contact with live parts can cause electric shocks, burns or even death. ▶ Only perform work on electrical equipment if you are an authorised electrician. ▶ Before you start working on electrical equipment: Switch off and lock out the power supply isolator and verify that no voltage is present.
-------------------	--

1.2.2 Notices

Messages that are not hazard-related are indicated with the signal word **NOTICE**. These messages do not have a safety alert symbol.

Format example of a message that is not hazard-related:

NOTICE	Operating the engine at an oil level below the minimum limit value can damage the engine. ► Regularly check the oil level and refill when necessary.
---------------	---

1.2.3 Other symbols



This symbol identifies a reference to an external document, such as an OEM manual.

1.3 Used terms and definitions

Term	Definition
CO ₂ set	The combination of the CO ₂ dosing unit and control panel.
CO ₂ dosing unit	The pre-assembled collection of components that transports the flue gases from the boiler to a greenhouse.
Greenhouse distribution system	The network that transports CO ₂ gas to one or more greenhouses.
Boiler	The heating appliance to which the CO ₂ dosing unit is connected. A water boiler is the most common type of heating appliance and will be used as the main example in this document.
Boiler house	The building in which the CO ₂ set and boiler are installed.
OEM manual	User manual of the original equipment manufacturer.

1.4 Conformity

Vitotherm CO₂ sets carry the CE and EAC marks as a proof of compliance to the following directives:

1. MD 2006-42-EG
2. EMC 2014-30-EU
3. LVD 2014-35-EU

See Appendix C for the full declaration of conformity.

[illegible]

2 Safety

2.1 Introduction

Observe the instructions in this manual before you start working with the CO₂ set. If you fail to follow the instructions from this manual you can put persons, surroundings, the environment and the CO₂ set at risk. Store this manual in an accessible place near the CO₂ set for future reference.

- ▶ Always comply with the information, such as labels and the type plate, attached directly to the CO₂ set and keep the information in a legible condition.
- ▶ Always comply with applicable local laws and regulations.



A Vitotherm CO₂ set is used in combination with a Vitotherm Automatic forced draught burner system. Refer to the instruction manual of the burner system for more information.

The CO₂ set is equipped with several safety components that ensure safe interaction with the machine.

2.2 Intended use

The Vitotherm CO₂ set is intended to be used in the following ways:

- As an electrically powered fan to collect the flue gases from a boiler system.
- To mix the collected flue gases with clean air to create CO₂ gas with the desired temperature.
- To deliver the dosed flue gases to the distribution system of a greenhouse.
- OPTIONAL – To mix the collected flue gases with clean air to regulate the under pressure in the connected CO₂ collector.

The Vitotherm CO₂ set is intended to be used under the following conditions:

- The CO₂ set must only be installed, operated, commissioned and maintained according to the instructions in this manual.
- The CO₂ set must only be used for an application in compliance with the requirements in the order confirmation.
- The CO₂ set must only be used under ambient conditions in compliance with the requirements in the order confirmation.
- The CO₂ set must only be used in compliance with applicable local laws and regulations.

Safe use of the CO₂ set is only guaranteed if it is used as intended.

2.3 Reasonably foreseeable misuse

The following is considered foreseeable misuse:

- Use of the CO₂ set that deviates from the intended use as described in the previous section.
- Failure to comply with the instructions in this manual.
- Failure to eliminate faults, malfunctions or defects of the CO₂ set that impose safety risks.
- Failure to carry out the inspections and maintenance operations as described in this manual.
- Unauthorized removal or modification of parts or safety components of the CO₂ set.
- Use of spare parts or accessories that have not been approved by the manufacturer.
- Operation in a closed-off or poorly ventilated room.

2.4 Qualification of personnel

Only authorised personnel is allowed to operate and clean the CO₂ set. They must possess the following qualifications:

- are legal of age;
- are familiar with and abide by the safety instructions and sections of this manual related to operating the CO₂ set;
- are familiar with and abide by the applicable local, national and international laws and regulations;
- are officially trained and certified by Vitotherm B.V.
- have received adequate training to operate and clean the CO₂ set;
- have obtained authorisation to access the CO₂ set.

Only authorised technicians are allowed to perform installation and maintenance of the CO₂ set. They must possess the following qualifications:

- are legal of age;
- are familiar and abide by the safety instructions and sections of this manual related to installation and maintenance of the CO₂ set;
- are familiar with and abide by the applicable local, national and international laws and regulations;
- are able to recognize the possible dangers of the CO₂ set and take the necessary measures to protect persons and property;
- have received adequate training in the safe maintenance of the CO₂ set;
- have obtained authorisation to access the CO₂ set.

2.5 Protective measures

2.5.1 Personal protective equipment (PPE)

Personnel that operates the CO₂ set must equip themselves with the following:



Wear foot protection



Wear eye protection



Wear ear protection (above 80 dB)

Technicians that install or perform maintenance on the CO₂ set must equip themselves with the following:



Wear foot protection



Wear eye protection



Wear protective gloves



Wear head protection (during lifting work)

2.5.2 Organizational measures

The owner is responsible for carrying out the necessary organizational measures to ensure safe use. Amongst other measures this is achieved by, but not limited to:

- Training and authorising personnel. Vitotherm is responsible for distributing passwords to authorised personnel only.
- Performing hazard assessments of the complete system that incorporates the CO₂ set and informing personnel of the possible dangers and protective measures.
- Performing good housekeeping in the facility that houses the CO₂ set.
- Running a preventive maintenance program.

2.6 Residual risks

Despite the safe design and construction of the CO₂ set and the prescribed protective measures, the CO₂ set poses residual risks. This manual provides safety messages to indicate these risks. The formatting and appearance of safety messages that are dedicated to a particular section or sentence are explained in chapter 1. Overall safety messages are grouped in the following sections.

2.6.1 Electricity

⚠ WARNING!

Contact with live parts can cause electric shocks, burns or even death.

- ▶ Only perform work on electrical equipment if you are an authorised electrician.
- ▶ Perform the work on electrical equipment in accordance with the local safety standards.
- ▶ Do not make changes to the CO₂ set if you are not qualified to do so.
- ▶ Before you start working on electrical equipment: Switch off and lock out the power supply isolator and verify that no voltage is present.
- ▶ Use fuses that correspond with the installed power of the CO₂ set.
- ▶ Regularly check the electrical wiring for loose connections and damage and repair them without delay.

2.6.2 Mechanical

⚠ WARNING!

The CO₂ set contains moving, pressurized and sharp parts that can crush, cut or hit.

- ▶ Do not operate the CO₂ set with covers or guards removed.
- ▶ Do not operate the CO₂ set with missing pipework or components.
- ▶ Never touch the air damper box during operation.
- ▶ Be aware of sharp edges.

2.6.3 Transport and storage

⚠ WARNING!

The CO₂ dosing unit may drop or topple when transported incorrectly.

- ▶ Use suitable hoisting equipment.
- ▶ Make sure no personnel is below or near the object when lifting or hoisting.

⚠ CAUTION!

The frame of the CO₂ set is made of steel and is sensitive to corrosion damage.

- ▶ Always store the CO₂ set in a dry, indoor location.
- ▶ Do not unpack the CO₂ set from the optional transport crate until you are ready to install it.

2.7 Warning labels

Always comply with warning labels and information signs on the CO₂ set. The warning labels and information signs must be kept legible and must be replaced if necessary. For this purpose, contact the manufacturer.

Symbol	Description	Location
	Do not insert your hands or limbs into the air inlet of the CO ₂ dosing unit.	Next to the air inlet of the CO ₂ dosing unit.

2.8 Safety precautions

A CO₂ set is equipped with several safety components that help prevent hazardous situations.

	For more information about the integration of the safety components into the system, please refer to the electrical wiring diagram.
---	---

2.8.1 Maximum temperature safety switch

The maximum temperature safety switch shuts down the CO₂ set if the flue gas temperature exceeds the set limit of 65 °C.

2.8.2 Air inlet grid

A protective grid is mounted on the air inlet of the CO₂ dosing unit. The grid prevents hands or limbs from entering the air inlet. Additionally, the grid prevents foreign objects or small animals from entering the air inlet and damaging the 2-way valve inside.


[illegible]

3 Design and function

The Vitotherm CO₂ set is designed to dose the flue gases from a boiler and transport the gas to a greenhouse, where it contributes to a healthy increase of crop growth.

3.1 System overview

The CO₂ set consists of the following components:




- 1 Boiler
- 2 Boiler chimney
- 3 CO₂ dosing unit
- 4 Control panel & frequency drive (optional)
- 5 Vitotherm CO detector (optional)
- 6 Scaffold (optional)

The fan of the CO₂ set sucks in the flue gases from the boiler chimney as well as clean air from the boiler house. A 2-way valve is integrated in the T-piece and modulates the ratio of flue gas and clean air, to control the temperature of the CO₂ gas that is transported to the greenhouse.

The air mixture is transported to the greenhouse via the air outlet on the fan housing. The fan housing can be mounted in different configurations to better align with the inlet of the greenhouse distribution system (see §3.8 for more information).

3.2 CO₂ dosing unit



- 1 Junction box
- 2 Fan housing
- 3 Modulating temperature controller
- 4 Air pressure sensor (LD3) - Transport monitoring
- 5 Maximum thermostat
- 6 Pressure transmitter (only with optional frequency control)
- 7 Connection sleeve with hose clamps (fan outlet)
- 8 Mounting frame
- 9 Air inlet & filter grid
- 10 2-way valve (air inlet)
- 11 2-way valve transmission arm
- 12 2-way valve servomotor
- 13 2-way valve (flue gas inlet)
- 14 Connection sleeve with hose clamps (flue gas inlet)

- 15 Type plate
- 16 Junction box fan motor
- 17 Fan motor
- 18 Hoisting holes
- 19 Scaffold connections

NOTICE

The exact location of the electronic components may differ based on the configuration of the fan housing (see §3.8).


NOTICE

The (optional) variation of the CO₂ set that is connected to a CO₂ collector has a different dosing unit. The following components are not included in this variation:

- ▶ Air inlet
- ▶ 2-way valve & servomotor
- ▶ Modulating temperature controller

3.3 Control panel

The CO₂ set is controlled with a separate control panel. It is recommended to install the control panel at an accessible height, close to the CO₂ set.



The following switches and lights are available on a standard control panel:

No.	Description		Function
1	Max. temperature failure light		Lights up red when the maximum flue gas temperature is exceeded.
2	Valve failure (ES6) light		Lights up red when a valve failure is detected. Only included together with the frequency control option (see §3.5.4).
3	Fan overload light		Lights up red when the load on the fan becomes too high.
4	Air pressure failure light		Lights up red when an air pressure failure is detected
5	CO ₂ request indication light		Lights up green when the dosing unit is able to receive flue gases.
6	Keyholes		Unlocks the control panel so that it can be opened.
7	Control switch	Computer	Switches the control to the external computer.
		Off	Switches the control off.
8	Reset button		Resets the CO ₂ set.
9	Main power switch		Switches the CO ₂ set on and off.

NOTICE

More information about the failures indicated by the lights on the control panel can be found in chapter 7 of this manual.

3.4 Frequency drive

Standard for VCU 3000 - 4500 and optional for smaller capacities

The frequency drive is located next to the control panel and is used to control the fan motor. The frequency drive is operated via the interface in the top left corner.


The frequency drive comes in two options:

- 380 - 480 V
- 500 - 600 V

Both options are equipped with a pressure sensor (0 – 100 mbar).

NOTICE

The factory settings of the frequency drive have been set by Vitotherm.



- 1 Graphical display with status information
- 2 Menu buttons and indicator LEDs
- 3 Navigation buttons and indicator LEDs
- 4 Operation buttons and indicator LEDs



For more information, please refer to the OEM manual.


3.5 Optional components

The following options are available for a Vitotherm CO₂ set.

3.5.1 Vitotherm CO detector

Type VCD2 with sampling pump


A Vitotherm CO detector checks the flue gas that is transported from the burner to external applications (e.g. greenhouses) for carbon monoxide. The CO detector is mounted near the flue gas exhaust.



For more information, please refer to the Vitotherm CO detector user manual.

3.5.2 Seaworthy packaging

If the CO₂ set needs to be well protected or shipped overseas, it can be packed in wooden crates treated according to ISPM 15.



3.5.3 Liquid CO₂ control

Built in the control panel

Control system which adds additional CO₂ in liquid form to the flue gases, in order to increase the CO₂ concentration of the gas supplied to the greenhouse.

3.5.4 Frequency control

A frequency control system can be added to the CO₂ set. This system uses a pressure transmitter to maintain a constant flue gas pressure and/or flow rate in the dosing unit.

3.6 Type plate

The CO₂ set is marked with a type plate in accordance with the applicable legislation requirements.



Vitotherm

Vitotherm BV
Lorentzstraat 1
2665 JG Bleiswijk
The Netherlands
☎ +31(0)15-3694757
www.vitotherm.nl

Type		•	1
Serial number		•	2
Production year		•	3
Destination country		•	4
Voltage	V	•	5
Frequency	Hz	•	6
Current	A	•	7
Fan type		•	8
Fan motor	kW	•	9
Blow-out position		•	10

This CO₂ fan must be installed according to the rules in force, and should be used only in a well ventilated area.

Before the CO₂ fan is installed and put into operation, the instruction manual must be read.

The electrical part of the burner is built according to the EN 60529, the voltage and amperage is as indicated on the nameplate of the burner.

When servicing the CO₂ fan the main switch must be switched off at all times.

- | | |
|--|---|
| 1. Type
2. Serial number
3. Year of manufacture
4. Country of destination
5. Voltage (V) | 6. Frequency (Hz)
7. Current (A)
8. Fan type
9. Fan motor
10. Blow-out position |
|--|---|

NOTICE

The location of the type plate is indicated in §3.1.

3.7 Technical data

For EU (50 Hz)

This section contains the standard dimensions, materials and performance data of a Vitotherm CO₂ set.

For technical data regarding your specific CO₂ set, please refer to the type plate (see §3.6) or the order confirmation. For performance data in imperial units, please refer to Appendix B of this manual.

Type	Fan motor power	* Motor voltage	3-way valve control	Inlet diameter (suction side)	Outlet diameter (pressure side)	Material fan housing, T-piece, fan.
	kW	VAC @ Hz	-	Ø mm	Ø mm	-
VCU220	2,2	400@50	Modulating	250	250	SS 304
VCU300	3,0	400@50	Modulating	250	250	SS 304
VCU400	4,0	400@50	Modulating	250	250	SS 304
VCU550	5,5	400@50	Modulating	300	315	SS 304
VCU750	7,5	400@50	Modulating	300	315	SS 304
VCU1100	11,0	400@50	Modulating	400	400	SS 304
VCU1500	15,0	400@50	Modulating	400	400	SS 304
VCU1850	18,5	400@50	Modulating	400	400	SS 304
VCU2200	22,0	400@50	Modulating	500	500	SS 304
VCU3000	30,0	400@50	Modulating	500	500	SS 304
VCU3700	37,0	400@50	Modulating	500	500	SS 304
VCU4500	45,0	400@50	Modulating	500	500	SS 304

* Motor voltage may vary per country (208, 400, 480 or 575 V @60 Hz).

3.8 Configurations

The fan housing can be mounted in 8 different discharge positions to better align with the inlet of the greenhouse distribution system. See Appendix A for an overview of the different discharge positions.

NOTICE

The standard configuration shown in this document is RD180 (4R).

4 Installation

This chapter provides instructions for the basic installation of a CO₂ set onto a boiler or other heating appliance. For information about a custom set-up, please contact Vitotherm.

⚠ CAUTION!

The CO₂ set may only be installed by qualified personnel. Handling the CO₂ set and supporting components without the required knowledge and experience may damage the CO₂ set or cause hazardous situations during installation and use.

⚠ WARNING!

The CO₂ set may only be installed in a sufficiently ventilated boiler house.

NOTICE

The CO₂ set must always be installed according to national and local laws and regulations.

4.1 Checking the delivery

Required tools:

- Forklift truck with adequate lifting capacity.

To check the delivery:

1. Transport the crate(s) to an accessible place near the boiler.
2. When delivered in an optional transport crate:
 - a. Remove the lid of the crate(s).
 - b. Remove the sides of the crate(s).
 - c. Remove the lashing straps and packaging materials.
 - d. Remove any screws that connect parts to the bottom of the crate(s).
3. Check if all parts have been delivered according to the agreed scope. If a part is missing, contact Vitotherm immediately.
4. Check all delivered parts for damage.

⚠ WARNING!

Damaged parts can affect the correct and safe functioning of the CO₂ set.

- ▶ Do not install damaged parts.
- ▶ If any parts are damaged upon delivery, please contact Vitotherm.

5. Check if the delivered CO₂ set will fit in the designated area of the room. For the dimensions of the CO₂ set, see §3.7.

4.2 Preparing the scaffold

The CO₂ dosing unit can be installed on a supporting scaffold. The mounting frame of the dosing unit can be expanded with legs to create this scaffold.

The CO₂ dosing unit can also be installed on the floor.

NOTICE

The scaffold or support feet are not part of the standard delivery and may have to be created as part of the installation process.

Connection materials:

- Square steel tubing (50 x 50 mm)
- Connection brackets

To prepare the scaffold:

1. Measure the required installation height and determine the required length of the frame legs. Use the dimensions in §3.7 as a reference.
2. Cut four pieces of square steel tubing with the required length.
3. Increase the stability of the scaffold:
 - a. Weld footpads onto the bottom of the frame legs.
 - b. Attach crosswise connector pieces between the frame legs.

4.3 Mounting the CO₂ dosing unit

Required tools:


- Mobile crane with adequate lifting capacity
- Suitable hoisting equipment:
 - D-shackles
 - Round sling
- Scaffold
- Power drill with steel drill head (Ø12 mm)
- Ring wrenches or adjustable spanners

⚠ WARNING!


The CO₂ dosing unit may drop or topple when transported incorrectly.

- ▶ Use suitable hoisting equipment.
- ▶ Make sure no personnel is below or near the object when lifting or hoisting.


To hoist the CO₂ dosing unit:



- 1 Connect your hoisting equipment to the hoisting eyes of the fan housing.
- 2 Carefully lift the dosing unit.
- 3 Place the scaffold below the dosing unit.



- 4 Align the mounting frame of the dosing unit with the scaffold.
- 5 Lower the dosing unit onto the scaffold.
- 6 Drill a hole through the bolt hole on the side of the connection point. Use a Ø12 mm steel drill.
- 7 Insert a Ø12 mm metal pin or bolt into the drilled hole.
- 8 Tighten the bolts in the connection points to secure the scaffold. Use a 16 mm wrench.



4.4 Connecting the CO₂ dosing unit

The flue gas inlet of the dosing unit must be connected to the boiler chimney.

The fan outlet of the dosing unit must be connected to the greenhouse distribution system.

Required tools:


- Mobile crane with adequate lifting capacity
- Suitable hoisting equipment:
 - D-shackles
 - Round sling
- Screwdriver

4.4.1 Connecting the boiler chimney


NOTICE

The tee connection for the intake and admixture can be swapped.


To connect the dosing unit to the boiler chimney:




1. Align the T-piece of the dosing unit with the outlet of the boiler chimney.



2. Loosen the outer hose clamp. Use a screwdriver.




3. Wrap the plastic sleeve around the outlet of the boiler chimney.



NOTICE

The boiler chimney outlet and the T-piece of the dosing unit may not touch each other to allow for movement. Leave a space of at least 10 cm between these two components.


4. Place the loosened hose clamp around the sleeve on the boiler chimney.




5. Tighten the clamp:
 - a. Use a screwdriver.
 - b. Make sure the connection is air tight.

4.4.2 Connecting the greenhouse distribution system


To connect the dosing unit to the greenhouse distribution system:




1. Align the outlet of the fan housing with the inlet of the greenhouse distribution system.




2. Loosen the outer hose clamp. Use a screwdriver.



3. Wrap the plastic sleeve around the inlet of the distribution system.



4. Place the loosened clamp around the sleeve on the distribution system.



5. Tighten the clamp:
 - a. Use a screwdriver.
 - b. Make sure the connection is air tight.

4.5 Electrical connections

All electric cabling is pre-wired to a junction box in the control panel. During installation, this cabling must be connected to the junction boxes on the CO₂ dosing unit (see §3.1).

NOTICE

For all electrical connections, the applicable local standards and the connection requirements must be taken into account.



For more information about the electrical connections and integrated circuits, please refer to the electrical wiring diagram.



5 Commissioning

Before commissioning the CO₂ set, make sure it meets the requirements below.

⚠ WARNING!	All mechanical screw connections (e.g. gas/oil line, flange connections, oil valves, electrical terminals) must be retightened prior to commissioning.
⚠ WARNING!	All components must be sealed with an appropriate sealant prior to commissioning.
⚠ WARNING!	The supporting burner system must be installed and commissioned according to the instruction in the corresponding instruction manual.
NOTICE	Commissioning of a Vitotherm installation may only be performed by certified personnel.
NOTICE	A commissioning report is created after the CO ₂ set has been successfully commissioned. Keep this report near the CO ₂ set for future reference.

- ☐ The CO₂ set is completely installed according to the instructions in this manual, including:
 - ☐ CO₂ dosing unit
 - ☐ Control panel & frequency drive (optional)
- ☐ Electrical wiring is completed according to the provided electrical wiring diagram, free of errors, so that the electrical pre-start condition circuit (safety chain) is closed. Completion of electrical field wiring to the control panel.
- ☐ Electrical power is available on the CO₂ set.
- ☐ Safety components are functioning correctly and ready for operation (see §2.8).
- ☐ Equipment supplied by third parties that is present in the control panel must be adjusted and programmed.
- ☐ Sufficient fresh air is available.
- ☐ The necessary local work permits are available.
- ☐ Qualified personnel is available for instructions, system transfer and site acceptance test.
- ☐ A safe workspace is available, according to health and safety regulations and realistic common sense.



6 Operation

This chapter describes the main operational procedures of the CO₂ set.

6.1 Control panel

The CO₂ set is controlled via the control panel. This panel has a control switches and several feedback LEDs. See §3.3 for an overview of the standard components of the control panel.

6.1.1 Main power switch

The control panel is activated by using the main power switch on the right side of the panel.

6.1.2 Internal components

The control panel can be opened with a key to gain access to:

- Relays and fuses
- A power outlet and modbus connection for a service laptop
- The USB drive with the technical file of the CO₂ set
- This instruction manual

⚠ WARNING!

Contact with live parts can cause electric shocks, burns or even death.

- ▶ Only perform work on electrical equipment if you are an authorised electrician.
 - ▶ Before you start working on electrical equipment, switch off and lock out the power supply isolator and verify that no voltage is present.
-

6.2 Switching the CO₂ set on or off

The CO₂ set is switched on or off with the main switch. This switch has two options:


- 1 = ON
- 0 = Off.

6.3 Performing a system reset

A system reset must be performed after a failure in the CO₂ set has been resolved. This procedure allows the CO₂ set to be put back into operation.

To reset the CO₂ set:

- Press the reset button on the control panel.




7 Troubleshooting

System failures are displayed on the interface of the control panel or frequency drive. The table below can be used to identify and solve the failure.



For more detailed information about these system failures, please refer to the OEM manual of the Lamtec operating system.

Description	Cause(s)	Solution(s)
Failure indication LED: Max. thermostat	Flue gas after CO ₂ temperature is too high.	1 Perform a system reset (see §6.3). 2 Check the modulating temperature control. Adjust if necessary.
Failure indication LED: Valve failure (ES6)	Valve servomotor has stopped working: jammed valve shaft	1 Dismount, clean and remount the 2-way valve servomotor. 2 Replace the servomotor if necessary.
	Valve servomotor has stopped working: jammed ball joint	1 Close the valve by hand. 2 Perform a system reset (see §6.3).
	Limit switch of the 2-way valve servomotor is set incorrectly.	Adjust the settings of the limit switch. Refer to the OEM manual for instructions.
The fan motor overrides the maximum current.	Fan or air inlet is obstructed.	Check the fan and air inlet and remove any obstructions.
	The motor runs on 2 phases.	Check the electrical wiring and fuses.
	The motor is defective.	Repair or replace the motor.
Minimum CO ₂ pressure failure (LD3)	Insufficient air is being transported through the dosing unit.	Check the fan housing outlet for obstructions. Check if the sleeve connections are airtight.
The condensation drain of the condenser is clogged.	Contamination	1 Remove the condenser inspection hatch. 2 Inspect the condensation drain.



8 Maintenance

8.1 Pre-emptive parts replacement schedule

Certain parts of the CO₂ set should be replaced every X years to prevent failure of vital components. The table below gives an overview of these maintenance activities and the frequency with which they should be performed.

Task	Interval (years)							To be carried out by
	1	2	5	8	10	15	20	
CO ₂ set								
2-way valve servomotor					●			
Temperature controller					●			
Pressure transmitter					●			
Pressure sensor (LD3)					●			
Maximum thermostat					●			
Connection sleeves			●					
Silicon gaskets (air outlet)			●					
Silicon seal strips (air inlet)			●					
VCD								
Pump		●						
CO sensor			●					
3-way valve			●					

8.2 Annual Periodic Maintenance

⚠ CAUTION!

To guarantee the quality and safety of the CO₂ set, Vitotherm advises annual Periodic Maintenance (PM) to be performed by their own certified service engineers.



This section contains maintenance instructions for the standard components of a CO₂ set. For maintenance instructions for any other (optional) components, please refer to the corresponding OEM manual.

8.2.1 Control panel

The following aspects of the control panel should be inspected:

- All electrical connections;
- The cables, for any sign of overload or burns;
- The circuit breaker fuses, for a correct rating;
- All switches and lights, for correct functioning;
- The cam timers, for correct functioning;

8.2.2 The CO₂ dosing unit

⚠ WARNING!

Make sure the burner system and CO₂ set are completely shut down before performing maintenance on the CO₂ dosing unit:

- ▶ Use the control switch on the control panel to close the fuel supply to the burner.
 - ▶ Interrupt the mains power supply to the burner system and CO₂ set.
 - ▶ Shut down the CO₂ set with the main switch on the control panel.
-

⚠ WARNING!

All mechanical screw connections must be retightened prior to every Periodic Maintenance.

Required tools:

- Ring wrenches or adjustable spanners
- Allen wrenches
- Screwdriver (slotted)

To perform Periodic Maintenance on the dosing unit of the CO₂ set, do the following:

1. Perform a visual check of all components for correct functioning.
2. Check the following parts for dirt or defects. Clean or repair if necessary:
 - a. The fan.
 - b. The fan motor.
 - c. The air inlet cover.
 - d. The 2-way valve.
3. Check if the 2-way valve opens smoothly.
 - a. Clean if necessary.
4. Check the welds on the mounting frame for any defects.
 - a. Repair if necessary.
5. Check the sleeve connections on the flue gas inlet and fan housing outlet for tears.
 - a. Replace if necessary.
6. Check if the safety precautions are in place and function correctly (see §2.8).

[illegible]



9 Transport and storage

This section contains instructions and information on how to properly transport and store the CO₂ set.

9.1 Transport


When transporting the components of the CO₂ set separately, use suitable hoisting or lifting equipment.

⚠ WARNING!

The CO₂ dosing unit may drop or topple when transported incorrectly.

- ▶ Use suitable lifting or hoisting equipment.
- ▶ Make sure no personnel is below or near the object when lifting or hoisting.

The CO₂ set is equipped with two hoisting eyes at the top of the fan housing. Hoisting equipment can be attached to these eyes as follows:



9.2 Storage

⚠ CAUTION!

The frame of the CO₂ set is made of steel and is sensitive to corrosion damage.

- ▶ Always store the CO₂ set in a dry, indoor location.
- ▶ Do not unpack the CO₂ set from the optional transport crate until you are ready to install it.

10 Decommissioning and disposal

This section contains instructions and information on how to properly decommission and dispose of the CO₂ set.

⚠ CAUTION!

The CO₂ set may only be installed by qualified personnel. Handling the CO₂ dosing unit and supporting components without the required knowledge and experience may damage the CO₂ set or cause hazardous situations during installation and use.

10.1 Decommissioning

To decommission the CO₂ set:

1. Use the control switch on the control panel to put the CO₂ set out of operation.
2. Shut down the CO₂ set with the main switch on the control panel.
3. Cut off the power source to the control panel.

10.2 Dismantling the CO₂ dosing unit

Required tools:

- Ring wrenches or adjustable spanners
- Allen wrenches
- Screwdriver (slotted)
- Mobile crane with adequate lifting capacity
- Suitable hoisting equipment:
 - D-shackles
 - Round sling

To dismantle the CO₂ dosing unit:

1. Disconnect all electrical connections.
2. Disconnect the dosing unit from the boiler chimney.
3. Disconnect the dosing unit from the inlet of the greenhouse distribution system.
4. Attach hoisting equipment to the dosing unit.
5. Loosen the bolts in the connection points of the scaffold.
6. Hoist the dosing unit and remove the scaffold from underneath.
7. Remove the electric components from the dosing unit (see §3.1):
 - a. Fan motor
 - b. Junction boxes
 - c. Servomotors
 - d. Air pressure sensor (LD3)
 - e. Pressure transmitter (optional)
 - f. Modulating temperature controller
 - g. Maximum thermostat
8. Remove the plastic connection sleeves.

10.3 Disposal

⚠ CAUTION!

Separate and dispose the components of the CO₂ set into the applicable waste streams based on their material, in accordance with local regulations.

NOTICE









All structural components of a Vitotherm CO₂ set are made of powder-coated steel and should be disposed of accordingly.



For more information on how to properly dispose of supplier parts, please refer to the OEM manual.

Appendices

A CO₂ dosing unit orientations

 IN OUT / UIT LG 270 (1L)	 OUT / UIT IN RD 270 (1R)																								
 IN OUT / UIT LG 0 (2L)	 OUT / UIT IN RD 0 (2R)																								
 IN OUT / UIT LG 90 (3L)	 IN OUT / UIT RD 90 (3R)																								
 IN OUT / UIT LG 180 (4L)	 IN OUT / UIT RD 180 (4R)																								
<table><tr><td colspan="2">Project-/drawing number:</td><td colspan="2">Description:</td><td colspan="2" rowspan="2"> Vito therm Gas- en oliebranders, Regel- en Beveiligingsapparatuur www.vitotherm.nl</td></tr><tr><td colspan="2">Co2 Units</td><td colspan="2">CO2 Fan Positions / CO2 Ventilator Posities</td></tr><tr><td colspan="2">Material: Stainless Steel / RVS</td><td rowspan="2">Drawn by: BB 21-4-2022</td><td rowspan="2">Form A4</td><td rowspan="2">Scale 1 : 45</td><td rowspan="2"></td></tr><tr><td colspan="2">Color: RAL 7016 (Grey / Grijs)</td></tr><tr><td colspan="2">Treatment: Powder coating / Poedercoaten</td><td colspan="2">Revision: B</td><td colspan="2"></td></tr></table>		Project-/drawing number:		Description:		 Vito therm Gas- en oliebranders, Regel- en Beveiligingsapparatuur www.vitotherm.nl		Co2 Units		CO2 Fan Positions / CO2 Ventilator Posities		Material: Stainless Steel / RVS		Drawn by: BB 21-4-2022	Form A4	Scale 1 : 45		Color: RAL 7016 (Grey / Grijs)		Treatment: Powder coating / Poedercoaten		Revision: B			
Project-/drawing number:		Description:		 Vito therm Gas- en oliebranders, Regel- en Beveiligingsapparatuur www.vitotherm.nl																					
Co2 Units		CO2 Fan Positions / CO2 Ventilator Posities																							
Material: Stainless Steel / RVS		Drawn by: BB 21-4-2022	Form A4	Scale 1 : 45																					
Color: RAL 7016 (Grey / Grijs)																									
Treatment: Powder coating / Poedercoaten		Revision: B																							

Copyright by Vitotherm

B Technical data

For NA (60 Hz)

Type	Fan motor power	* Motor voltage	3-way valve control	Inlet diameter (suction side)	Outlet diameter (pressure side)	Material fan housing, T-piece, fan.
	HP	VAC @ Hz	-	Ø inch	Ø inch	-
VCU220	3.0	400@50	Modulating	9 ²⁷ / ₃₂	9 ²⁷ / ₃₂	SS 304
VCU300	4.0	400@50	Modulating	9 ²⁷ / ₃₂	9 ²⁷ / ₃₂	SS 304
VCU400	5.4	400@50	Modulating	9 ²⁷ / ₃₂	9 ²⁷ / ₃₂	SS 304
VCU550	7.4	400@50	Modulating	11 ¹³ / ₁₆	12 ¹³ / ₃₂	SS 304
VCU750	10.1	400@50	Modulating	11 ¹³ / ₁₆	12 ¹³ / ₃₂	SS 304
VCU1100	14.8	400@50	Modulating	15 ³ / ₄	15 ³ / ₄	SS 304
VCU1500	20.1	400@50	Modulating	15 ³ / ₄	15 ³ / ₄	SS 304
VCU1850	24.8	400@50	Modulating	15 ³ / ₄	15 ³ / ₄	SS 304
VCU2200	29.5	400@50	Modulating	19 ¹¹ / ₁₆	19 ¹¹ / ₁₆	SS 304
VCU3000	40.2	400@50	Modulating	19 ¹¹ / ₁₆	19 ¹¹ / ₁₆	SS 304
VCU3700	49.6	400@50	Modulating	19 ¹¹ / ₁₆	19 ¹¹ / ₁₆	SS 304
VCU4500	60.3	400@50	Modulating	19 ¹¹ / ₁₆	19 ¹¹ / ₁₆	SS 304

*Motor voltage may vary per country (208, 400, 480 or 575 V @60 Hz).

C Declaration of conformity



Declaration of conformity

Manufacturer:	VITOTHERM B.V.												
Address:	Lorentzstraat 1 2665 JG Bleiswijk Netherlands												
Products:	CO2 dosing unit & control panel												
Type:	VITOTHERM B.V. CO2 dosing unit types: <table><tr><td>VCU 220</td><td>VCU 1500</td></tr><tr><td>VCU 300</td><td>VCU 1850</td></tr><tr><td>VCU 400</td><td>VCU 2200</td></tr><tr><td>VCU 550</td><td>VCU 3000</td></tr><tr><td>VCU 750</td><td>VCU 3700</td></tr><tr><td>VCU 1100</td><td>VCU 4500</td></tr></table>	VCU 220	VCU 1500	VCU 300	VCU 1850	VCU 400	VCU 2200	VCU 550	VCU 3000	VCU 750	VCU 3700	VCU 1100	VCU 4500
VCU 220	VCU 1500												
VCU 300	VCU 1850												
VCU 400	VCU 2200												
VCU 550	VCU 3000												
VCU 750	VCU 3700												
VCU 1100	VCU 4500												
Applications:	VITOTHERM CO2 dosing units for greenhouses CO2 transportation fan												
Standards:	Mentioned products are in compliance with the following technical standards: NEN EN-ISO 14120 ISSO 86												
Directives:	Mentioned products are according the following European directives: EMC 2014-30-EU MD 2006-42-EG LVD 2014-35-EU												
Protection class IP:	Degree of protection IP54 IP - EN 60529												
Marking of type plate:	The CO2 dosing units are labelled with: CE mark HortiQ												

2024-v1

Vitotherm BV

Lorentzstraat 1
2665 JG Bleiswijk
T (+31) 015 369 47 57
info@vitotherm.nl
www.vitotherm.nl